



Snorkel

The snorkel will eliminate water back up into your abrasive delivery system. We have all experienced nozzle clogging due to trash or inconsistent abrasive.

- Eliminates down time due too water back up into the mini hopper
- Only takes minutes to be running again.
- New design eliminates lose of vacuum, Check Ball seats perfect every time
- Unclog nozzle, shake abrasive out of the line below Snorkel and start cutting.
- Can be utilized on any machine running abrasive

Installation Procedures

Cut abrasive line four inches below your mini hopper or abrasive delivery system and install the Snorkel with check ball in the upright position.

When ordering please let us know the size of your abrasive line so that we can supply the right size hose nipples for your application.

